



2007-2018 Tie Rod End Installation

WARNING! Please read and understand these instructions completely before installing to avoid possible injury to yourself or damage to the parts or your vehicle.

KRYPTONITE JOINTS ARE PRE-GREASED AND DO NOT REQUIRE ADDITIONAL GREASE!

1. Be sure to verify you have a factory end (Figure 1)
2. On a flat and level surface chock rear tires and lift front of vehicle supporting it with jack stands. Remove wheel/tire.
3. Measure OE tie rod from edge of boot to center of outer end. (Figure 2) Record measurements:

D	P
---	---
4. Remove outer tie rod end from inner (Figure 3). Remove jam nut if you're installing KRSLV11

