

1. Turn the wheel to give working space to the front of the front wheel wheel-well liner.
2. Remove (6) T-15 Torx screws from the front and center of the wheel-well liner. Then, pull the front of the wheel-well liner away from the front bumper to reveal the inner bumper components.
3. Remove (3) 7mm screws securing the sidemarker to the bumper. Use the new LED lighting as a template to locate the hardware.
4. Locate the sidemarker lens connector. Slide the red connector back, and unplug the connector.
5. Identify the LH/RH lights using the labels embossed in the light housings.
6. Fit and secure the new LED light into the bumper using the original 7mm screws. Plug in and test the lighting.
7. Re-install the wheel-well using the original Torx screws.
8. Repeat Steps 1-7 for the remaining LED light. Installation is now complete.



LED FRONT SIDEMARKERS

(2025+ YUKON / TAHOE)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Sidemarker Lamp
(1) RH Sidemarker Lamp

TOOLS REQUIRED

Phillips Screwdriver

SKU # CT40859