

V2 LED SIDE MARKER LAMPS

(2020-2025+ SIERRA 2500 / 3500)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Side Marker Lamp
- (1) RH Front Side Marker Lamp
- (1) LH Rear Side Marker Lamp
- (1) RH Rear Side Marker Lamp
- (4) Plastic Push Clips

TOOLS REQUIRED

T-15 Torx Socket / Bit T-20 Torx Socket / Bit Ratchet Panel Removal Tool

> SKU # HG53426 / HG53427 / HG53428 / HG53429



Front Installation

- 1. Locate the various T-15 Torx screws and plastic push clips from the inner fender liner. Then, remove the fender liner from the vehicle.
- 2. Remove (2) T-20 Torx screws from the back of the OEM side marker lamp. Then, lift the red connector lock and unplug the electrical connector.
- 3. Plug in and fit the appropriate marker lamp to the vehicle, and secure using the original (2) T-20 Torx screws. Re-install the vehicle fender liner using OEM hardware. Repeat Steps 1-3 for the opposite side installation.

Rear Installation

- 1. Remove (5) T-15 Torx screws from the rear mud flap. Then, pull the mud flap down to remove from the fender flare.
- To remove the fender flare from the vehicle, firmly pull the fender flare away from the body, there is no hardware holding the flare to the bed, only plastic clips.
- 3. Lift the red connector lock and unplug the electrical connector. Then, remove (2) T-20 Torx screws from the side marker lamp.
- 4. Plug in and fit the appropriate marker lamp to the vehicle, and secure using the original (2) T-20 Torx screws. Re-install the vehicle fender flare and mud flap using OEM hardware. Repeat Steps 1-4 for the opposite side installation.

Installation is now complete.