

V2 LED SIDE MARKER LAMPS

(2020-2025+ SIERRA 2500 / 3500)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Side Marker Lamp
- (1) RH Front Side Marker Lamp
- (1) LH Rear Side Marker Lamp
- (1) RH Rear Side Marker Lamp
- (4) Plastic Push Clips

TOOLS REQUIRED

- T-15 Torx Socket / Bit
- T-20 Torx Socket / Bit
- Ratchet
- Panel Removal Tool

SKU # HG53426 / HG53427 /
HG53428 / HG53429

Front Installation

1. Locate the various T-15 Torx screws and plastic push clips from the inner fender liner. Then, remove the fender liner from the vehicle.
2. Remove (2) T-20 Torx screws from the back of the OEM side marker lamp. Then, lift the red connector lock and unplug the electrical connector.
3. Plug in and fit the appropriate marker lamp to the vehicle, and secure using the original (2) T-20 Torx screws. Re-install the vehicle fender liner using OEM hardware. Repeat Steps 1-3 for the opposite side installation.

Rear Installation

1. Remove (5) T-15 Torx screws from the rear mud flap. Then, pull the mud flap down to remove from the fender flare.
2. To remove the fender flare from the vehicle, firmly pull the fender flare away from the body, there is no hardware holding the flare to the bed, only plastic clips.
3. Lift the red connector lock and unplug the electrical connector. Then, remove (2) T-20 Torx screws from the side marker lamp.
4. Plug in and fit the appropriate marker lamp to the vehicle, and secure using the original (2) T-20 Torx screws. Re-install the vehicle fender flare and mud flap using OEM hardware. Repeat Steps 1-4 for the opposite side installation.

Installation is now complete.