

SLEEKSTER™

FRAME MOUNTED LIGHT BARS

By Randy Ellis Design Inc.

U.S. DESIGN PATENT NO. D521,923



INSTALLATION INSTRUCTIONS

Part # 3005 + 3405 ('03-'18 Dodge 2500/3500)

Note: On sport model trucks, the light bar brackets may interfere with the bumper cover, touching the underside of the bumper opening. If installing on sport model truck the bumper can be realigned to minimize interference.

Supplied hardware:

7/16"-14 x 2-1/4" bolt (8)

7/16" flat washer (16)

7/16"-14 lock nut (8)

1. If your Dodge does not have factory tow hooks, go to step 6.
2. If your Dodge has factory tow hooks, remove the tow hooks.
3. Locate your new light bar so the brackets will sandwich between the tow hooks and the frame.

NOTE: The light bar needs to be "rolled" into place by inserting the lower end of the brackets into the opening first and "rolling" it up into position.

4. Re-install the tow hooks, using the factory tow hook bolts with the bolts going through the tow hook, the light bar bracket and then the frame brackets. Do not tighten.
5. Align the light bar side to side until it is centered in the opening and then tighten all hardware.
6. If your Dodge does not have the factory tow hooks, remove the plastic filler panels or panel in the opening of the middle of the bumper.
NOTE: Factory tow hooks and hardware can be purchased at your local Dodge dealership if you would like to install tow hooks at this time. Tow hooks are not necessary for the installation of the light bar.
7. Notice the 4 holes in the frame on each side that line up with the light bar brackets.
8. Install the light bar using the supplied hardware. Do not tighten.
NOTE: The light bar needs to be "rolled" into place by inserting the lower end of the brackets into the opening first and "rolling" it up into position.
9. Align the light bar side to side until it is centered in the opening and then tighten all hardware.

Install the lights of your choice and enjoy!

**Thank you for purchasing quality products from Randy Ellis Design, Inc.
Please call us at 602-803-1122 if you have any questions or problems.**

Randy Ellis Design, Inc.
2855 W. Fairmount Ave., Phoenix, AZ 85017
Phone: 602-803-1122
Web: www.randyellisdesign.com
E-mail: team@randyellisdesign.com

SLEEKSTERTM

FRAME MOUNTED LIGHT BARS

By Randy Ellis Design Inc.

U.S. DESIGN PATENT NO. D521,923



ADDITIONAL NOTE

Part # 3005 + 3405 ('03-'18 Dodge 2500/3500)

Note: On 2015 models, factory tow hook bolts are larger than normal & will require holes in the light bar brackets to be opened up to 1/2.".

Note: On some 2012-Newer Power Wagons the factory tow hook bolts are larger than normal & may require holes in the light bar brackets to be opened up to 1/2.".

Please call us at 602-803-1122 if you have any questions or problems.

Please call us at 602-803-1122 if you have any questions or problems.

Randy Ellis Design, Inc.

2855 W. Fairmount Ave., Phoenix, AZ 85017

Phone: 602-803-1122

Web: www.randyellisdesign.com

E-mail: team@randyellisdesign.com