



LED CAB CLEARANCE LIGHTS

(2003-2018 2500/3500)

INSTALLATION INSTRUCTIONS

CONTENTS

(5) LED Cab Lights

TOOLS REQUIRED

T-20 Torx Socket/Key
Ratchet
Exterior Detailer
Microfiber Cloth



STEP 1

Locate the vehicle cab light, and remove the (2) T-20 Torx screws.

Note: Ensure the gasket remains installed on each screw.



STEP 2

Using moderate pressure, dislodge the vehicle cab light from the vehicle. Twist the light socket counter-clockwise to remove the light bulb from the light housing.



STEP 3

Remove the light bulb from the light socket.

Clean the vehicle paint using exterior detailer and a microfiber cloth to remove any dirt from around the original cab light.



STEP 4

Plug the cab light electrical connector into the vehicle wiring harness. Then, insert the vehicle light socket into the new cab light housing and twist clockwise to lock into place.

Note: Some vehicles have polarized connections. If the light does not power on initially, unplug the light connector, turn the connector 180 degrees, and re-plug in the connector and then test the light.



STEP 5

Secure the LED cab light to the vehicle using the original (2) T-20 Torx screws. Secure the hardware evenly to ensure the light is sealed properly.



STEP 6

Repeat steps 1-5 for the remaining LED cab lights.

Installation is now complete.