
BARRICADE

HD4 HD BN Hoop with Skid Plate 19-24 Dodge Ram 2500-3500

Installation Instructions

PARTS LIST: HR61447

| Qty | Item Description | Qty | Item Description |
|-----|--|-----|--|
| 1 | HD4 Skid Plate | 2 | M8 Single Bolt Plates |
| 1 | HD4 HD Bull Nose Hoop | 6 | 8-1.25mm x 25mm Button Head Bolts |
| 1 | Driver/left Skid Plate Mount Bracket | 2 | 8-1.25mm x 25mm Hex Bolts |
| 1 | Passenger/right Skid Plate Mount Bracket | 2 | 8-1.25mm x 16mm Hex Bolts |
| 1 | Driver/left Light Mount Bracket | 20 | 8mm x 24mm OD x 2mm Large Flat Washers |
| 1 | Passenger/right Light Mount Bracket | 12 | 8mm Lock Washers |
| 3 | 10-1.5mm x 25mm Button Head Bolts | 10 | 8mm Hex Nuts |
| 3 | 10mm x 30mm OD x 2.5mm Flat Washers | 1 | 6mm Allen Wrench |
| 3 | 10mm Lock Washers | 1 | 5mm Allen Wrench |



TOOLS REQUIRED





13mm Socket










Wrench

Follow (Fig 1 – 3) to attach BN Hoop to LD Bumper, then attach LED Brackets and LED Light as necessary. Ensure BN Hoop is level before tightening fasteners.







(Fig 2) Attach BN Hoop to **Front Mounting Point**

4

Follow (Fig 4-8) to attach Skid Plate to Bumper. Ensure Skid Plate is level and fits well before tightening hardware. Installation is complete. Do periodic inspection to the installation to make sure that all hardware is secure and tight.

