# 2013-2016 Dodge/Jeep, Car/Truck 5.7L/6.1L/6.4L

# 85 & 90mm Throttle Body

Part #1842,1843



Special Tools

Required:

Approximately
1 Hour

Install Time:

 No special tools required

Difficulty:

1 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

# !!!REMOVAL OF THE SIDE COVER WILL VOID WARRANY!!!

With this throttle body you will be re-using the stock rubber gasket and the four stock bolts that retain the throttle body.

## STEP 1

Disconnect the negative battery terminal.

## STEP 2

 Disconnect the air temperature sensor plug and the throttle body control motor plug.

#### STEP 3

 Loosen the clamps on the air intake tube and air box, and then remove the tube.

#### STEP 4

 Remove the four bolts that secure the throttle body to the intake manifold.

#### STEP 5

 Remove the stock throttle body. The stock Oring seal will be re-used. Be sure to wipe off and debris from the gasket.

### STEP 6

 Bolt on the BBK Throttle Body using the stock hardware. On the 5.7L Hemi Plastic manifolds, take extra care when re-installing the mounting bolts. The "Speed Nut" type threaded nuts can be easily stripped. Make sure the threads of the bolts are properly engaged with the nut before tightening.

#### STEP 7

 Re-install the air inlet tube to the BBK Throttle Body and air box and then tighten the clamps.

### STEP 8

 Re-connect the air temperature sensor and the throttle body control motor plug. Re-connect the negative battery terminal and refer to page 2 of the instruction sheet for throttle relearn procedure.



Join our Facebook page www.facebook.com/bbkperformance





Check us out on Youtube www.youtube.com/bbkperformance

GO TO NEXT PAGE





For any questions, email us: tech@bbkperformance.com

installation instructions



2013-2016 Dodge/Jeep, Car/Truck 5.7L/6.1L/6.4L

# 85 & 90mm Throttle Body

Part #1842,1843



THROTTLE POSITION/GAS PEDAL RELEARN PROCEDURE FOR THE BBK #1842 AND #1843 THROTTLE BODIES FOR THE CHRYSLER/DODGE 5.7, 6.1, 6.4L HEMI ENGINE

Gas pedal/Throttle Body idle relearn process

With the addition of the larger bore throttle body and its larger intake flap, the gas pedal and throttle body must be re-synched before starting the engine. This must be done to prevent a check engine light for "increased idle" The procedure is simple.

After installation instructions are complete, please follow the procedures below. If throttle body has already been installed, please just follow steps 1-4.

- 1. Disconnect battery for 5 minutes. Reconnect. (or use a code reader to clear any stored codes in the computer) NOTE: If this is a new install, proceed to step 2.
- 2. Turn ignition key to on position, do not start the engine.
- 3. Slowly depress the gas pedal to the floor, and then slowly release it. Do this three (3) times. Turn the key off.
- 4. Now start engine. The gas pedal is now in synch with the larger throttle body.















