

INSTALLATION INSTRUCTIONS FOR

DYNOMAX KIT: 39498

2014-09 Dodge Ram 1500 4.7L, 5.7L, All Cab Types,
2 / 4 W.D., Single Exhaust System



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER OR SCISSOR" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the original exhaust system from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. If your vehicle is a regular cab, 6½' box (120" W.B.), slip a **36439** 3" band clamp on the inlet end and install DynoMax inlet pipe **54716**. If your vehicle is a regular cab, 8' box, or quad cab, 6½' box (140" W.B.), slip a 36439 3" band clamp on the inlet end and install front extension pipe **52461** first, then install inlet pipe 54716. Insert the rod hanger welded to 54716 into the OE rubber isolator hanger. Also locate the other rubber isolator hanger and install clamp-on rod hanger 36492. Please see the system diagram for details.
3. Install DynoMax Ultra Flo Welded muffler **17547**, using the **33272** 3" band clamps, as shown in the system diagram. Either end of the muffler can be installed as the inlet.
4. Install DynoMax tail pipe **55546**. Insert the metal rod hangers into the rubber isolators on the crossmember and frame.

5. Beginning at inlet end align the system and fully tighten all the clamps.
6. Please see the system diagram on the back page of these instructions

KIT CONTAINS:

- (1) 17547 MUFFLER
- (1) 54716 INLET PIPE
- (1) 52461 EXTENSION PIPE
- (1) 55546 TAIL PIPE
- (1) 36492 HANGER
- (2) 36439 3" BAND CLAMPS
- (2) 33272 3" BAND CLAMPS
- (1) 710635 INSTRUCTION SHEET

39498 SYSTEM DIAGRAM

