



# LED THIRD BRAKE LIGHT

(2002-2008 1500, 2003-2009 2500 & 3500)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Third Brake Light

### TOOLS REQUIRED

---

Phillips Screwdriver  
Plastic Pry Tool



**STEP 1**

Remove (2) Phillips head screws from the third brake light assembly.



**STEP 2**

With the screws removed, remove the brake light from the vehicle using a plastic pry tool. Unplug the electrical connector from behind the brake light.



## STEP 3

Plug in the brake light electrical connector into the vehicle's wiring harness. Toggle the switch to enable 5x strobe feature.



## STEP 4

Reassemble the vehicle using the original hardware. Tighten until secure.

Installation is now complete.