



TOWING MIRROR EXTENSIONS FOR OEM MIRRORS

(2009-2016 RAM 1500)

(2011-2016 RAM 2500)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Mirror Extension
(1) RH Mirror Extension

TOOLS REQUIRED

Isopropyl Alcohol
Microfiber Cloth

SKU # R119935

**STEP 1**

Clean the outside of the vehicle mirror with isopropyl alcohol and a microfiber cloth. Peel back the tape backing on the double sided tape. Hinge the top of the mirror cover over the vehicle mirror, ensuring the (2) front clamping tabs are on the edge of the mirror.

**STEP 2**

Hinge the lower portion of the mirror extension under the vehicle mirror. Ensure the (2) mounting clamps attach to the vehicle mirror lip. Firmly press on the back side of the mirror extension to ensure proper double sided tape adhesion.

Installation is now complete.