



ANTENNA BASE COVER

(2009-2018 RAM 1500)

(2010-2018 RAM 2500 3500)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Antenna Base Cover

TOOLS REQUIRED

Adjustable Wrench
Pliers/Channel Locks
Exterior Detailer
Microfiber Cloth

SKU # R119937

STEP 1

Using an adjustable wrench, loosen and remove the antenna from the vehicle.

STEP 2

Using pliers or channel locks, loosen the nut at the top of the antenna base. Un-thread the nut entirely and set aside. The nut will be reused for assembly.

Note: Wrap the pliers with a rag to prevent damage to the protective coating on the nut.

STEP 3

Lift the antenna base cover from the vehicle. Clean any dirt and debris previously captured by the antenna base from the vehicle using exterior detailer and a microfiber cloth.

STEP 4

Install the new antenna base to the vehicle following steps 1-3 in reverse order.

Installation is now complete.