



AIR VENT MOUNTED PHONE HOLDER

(UNIVERSAL FITMENT)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Vent Clamp
(1) Locking Nut
(1) Phone Holder

TOOLS REQUIRED

N/A

SKU # J152412

STEP 1

Assemble the phone holder. With the nut onto the clamp stud, insert the stud into the phone holder. Thread but do not fully tighten the nut to ensure the holder is attached to the clamp.

STEP 2

Press in the clamp, then align to the vehicle air vent. Release the clamp, allowing the clamp to expand into the vent. Insert the phone by separating the top wings on the holder. Place phone inside the (3) mounting points. Tighten nut when the mount is at an appropriate angle.

Installation is now complete.