



RAM

LOCKING ROLL-UP TONNEAU COVER

(2009-2018 RAM 1500 - 5.7' BOX; WITHOUT RAM BOX)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Tonneau Cover
- (1) LH Bed Rail
- (1) RH Bed Rail
- (6) Bed Rail Clamps
- (3) Cross Bars
- (1) Allen Key

TOOLS REQUIRED

- Phillips Screwdriver
- Allen Key (Provided)

SKU # R134397-A , R134397-B

STEP 1

Place the side rails onto each side of the vehicle bed rails. Ensure the locking portion of the rail is towards the tailgate.

STEP 2

Using (3) bed rail clamps, place the clamps evenly along the side rail, avoiding the cross bar cutouts in the rail. Loosely secure the side rail to the vehicle, this will allow for adjustments later.

STEP 3

Insert the tonneau cover into the side rails, and secure using the thumb screw on each side of the tonneau cover.

STEP 4

Place the cross bars into the cutouts in the side rails.

Note: The cross bars are directional and slightly angled. The angle must face away from the bed.

STEP 5

Un-roll the tonneau cover towards the rear of the vehicle. Tuck the plastic trim along the sides of the tonneau cover under the outer edge of the side rail on both sides. Secure the tonneau cover into the locking portion of the side rail, and adjust the tonneau cover until proper adjustment is achieved.

STEP 6

Once properly adjusted, tighten all (6) side rail clamps until secure.

To store the tonneau cover, pull the tonneau cover release and roll the tonneau cover towards the vehicle cab, and lock into place using the (2) straps. Remove the (3) cross bars from the side rails.

Installation is now complete.