



SOFT ROLL UP TONNEAU COVER

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Tonneau Cover
- (1) LH Side Rail
- (1) RH Side Rail
- (6) Clamps w/ Thumb Screws
- (1) Allen Key

TOOLS REQUIRED

Allen Key (Provided)

STEP 1

Place the tonneau cover onto the truck bed bulkhead. With the (1) Allen bolt and nut loose, slide the side rail into the tonneau cover assembly. Ensure the nut is installed into the recess.

Repeat this step for the opposite side rail.

STEP 2

With the rail connected on each side, tighten the Allen bolt to secure the tonneau cover to the side rail on each side of the vehicle.

STEP 3

Align the tonneau cover to the vehicle with the tailgate up to determine proper alignment on the bulkhead and the tailgate. Install the (6) clamps to the side rail to secure the side rails to the bed rails. Unfold the tonneau cover to ensure clamp placement does not interfere with the tonneau cross-bars.

STEP 4

Loosen the (2) Allen bolts on the adjuster at the end of each side rail. Unfold the tonneau cover to attempt to latch closed. Move the adjuster until the cover is a tight latch. If the adjuster is too loose, the tonneau cover will not latch down. Once properly adjusted, fully tighten the adjuster into place.

STEP 5



Installation is now complete.