



BLACK HORSE OFF ROAD®

Installation Instructions

Auto Safe

Part# ASDR02 Fits: - Ram 1500 2020-2023





Installation:

- STEP 1** Empty the armrest box including the mat at the bottom.
- STEP 2** Place the 2 side brackets into the armrest box.
- STEP 3** Put the top panel of the safe on the brackets and ensure that the screw threads are exposed.
- STEP 4** Open the lid, screw the acorn nuts on to the exposed threads, then use the Wrench to tighten the nuts. Do not overtighten the nuts, overtightening may damage the threads.
- STEP 5** Screw the Self-tapping Screws through the 4 holes of the safe into the bottom of the armrest box.

Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided and keep in a safe place.

Installing the Safe