

LED MIRROR TURN SIGNALS

(2010-2023+ 1500 / 2500 / 3500)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH LED Mirror Turn Signal
- (1) RH LED Mirror Turn Signal

TOOLS REQUIRED

T-15 Torx Screwdriver

STEP 1



Adjust the mirrors to allow your hand to fit behind the small mirror glass.

STEP 2



Pull firmly on the side mirror glass to dislodge the mirror glass away from the mirror assembly retainers. This may require moderate pressure, the mirror glass is intended to be removable.

STEP 3



Unplug the electrical connector from the mirror turn signal light housing.

STEP 4



Remove (1) T-15 Torx screw from the turn signal light housing. Remove the vehicle turn signal light from the vehicle mirror.

Note: The original (1) T-15 Torx screw will be reused.



STEP 5

Fit the new mirror turn signal lamp into the mirror, and ensure the lamp is properly seated. Secure the lamp into place reusing the original (1) T-15 Torx screw.

Re-assemble the vehicle mirror following steps 1-4 in reverse order.



STEP 6

Repeat steps 1-5 for the opposite side mirror turn signal lamp.

Installation is now complete.