

LED PUDDLE LIGHTS

(2010-2018 1500 / 2500 / 3500)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Puddle Lights
(1) RH Puddle Lights

TOOLS REQUIRED

Small Flathead Screwdriver

STEP 1



Using a small flathead screwdriver, fit the screwdriver against the original puddle lamp, and pry down to dislodge the retaining clip. Use the new puddle lamp as a retaining clip locating reference.

STEP 2



Unplug the puddle lamp spade connectors from the puddle lamp assembly. Use a small flathead screwdriver gently if necessary for additional leverage.

STEP 3



Fit each new puddle lamp spade connector into the corresponding vehicle wiring harness connectors.

STEP 4



Hinge the new puddle lamp into the mirror assembly, and press into place until the lamp is locked into place.



STEP 5

Repeat steps 1-4 for the remaining puddle lamp.

Installation is now complete.