



OUT-CHANNEL WINDOW GUARDS

(2019-2025+ 1500 CREW CAB)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Set of Window Guards

TOOLS REQUIRED

Isopropyl Alcohol
Microfiber Cloth

SKU # R175554

STEP 1



Clean the vehicle surface/weatherseal using isopropyl alcohol and a microfiber cloth, and allow to fully dry. Test fit the appropriate window guard to the vehicle to familiarize fitment.

STEP 2



Once familiar with fitment, peel the red tape backing from the window guard. Firmly press the window guard to the vehicle to ensure proper adhesion.

Repeat steps 1-2 for all remaining window guards.

Installation is now complete.