

## 2019-2024 RAM 1500/2500/3500 Full LED Tail lights SKU 311477/ 311478

Modified on: Wed, Jun 21, 2023 at 1:53 PM

2019-2024 RAM 1500/2500/3500 Full LED Tail lights

SKU# 311477, SKU# 311478



"DON'T GET LEFT IN THE DARK"



**19-24 DODGE RAM 1500**



**FOR OE HALOGEN MODELS**

CONNECT THE OE FACTORY CONNECTOR DIRECTLY TO THE NEW TAIL LIGHT CONNECTOR. THE NEW LIGHTS ARE PRE-INSTALLED WITH THE HALOGEN HARNESS. ONLY REFER TO THE NEXT STEPS IF YOUR OE TAIL LIGHTS ARE THE LED MODELS.



**FOR OE LED MODELS WITHOUT BLIS**

CONNECT THE OE FACTORY CONNECTOR DIRECTLY TO THE NEW TAIL LIGHT CONNECTOR. THE NEW LIGHTS ARE PRE-INSTALLED WITH THE HALOGEN HARNESS. ONLY REFER TO THE NEXT STEPS IF YOUR OE TAIL LIGHTS ARE THE LED

**FOR OE LED MODELS WITH BLIS**

REFER TO 12 STEPS BELOW



**STEP 1**

**REMOVE OEM BLIS MODULE**

USE T20 TORX BIT AND UNSCREW THE 4 CIRCLED SCREWS TO REMOVE BLIS ASSEMBLY FROM OE LIGHT.

(DRIVER SIDE/LEFT SHOWN IN PHOTO)



**STEP 2**

**REMOVE OEM BLIS MODULE**

USE T20 TORX BIT AND UNSCREW THE 2 SCREWS TO REMOVE BLIS SENSOR FROM BLIS HEAT SINK.

REPEAT STEP 1 & 2 ON OPPOSITE SIDE



**STEP 3**

**DISCONNECT BLIS MODULE**

PRESS DOWN ORANGE TAB ON BLIS SENSOR CONNECTOR AND DISCONNECT BLIS SENSOR.

\* DO NOT DROP OEM BLIS MODULE \*



**STEP 4**

**SET BLIS SENSOR ASSEMBLY ASIDE FOR LATER USE**

\* DO NOT DROP OEM BLIS MODULE \*  
REPEAT STEP 1 & 2 ON OPPOSITE SIDE



**STEP 5**

**REMOVE BLIS COVER ON NEW TAIL LIGHT**

REMOVE SCREWS FROM BLIS COVER FROM NEW LIGHT. PRESS DOWN TAB ON CONNECTOR AND DISCONNECT.



**STEP 6**

**REMOVE HALOGEN HARNESS**

REMOVE PRE-INSTALLED HALOGEN MODEL HARNESS WITH RESISTORS, PRESS DOWN BLACK TAB ON HARNESS TO DISCONNECT.



**STEP 7**

**SET ASIDE AND STORE**

SET ASIDE/STORE HALOGEN HARNESS AND RESISTORS.


REPEAT STEP 5 & 6 ON OPPOSITE SIDE



**STEP 8**

**INSTALL BLIS MODULE ON NEW TAIL LIGHT**

LOCATE BLIS ASSEMBLY REMOVED FROM OE TAIL LIGHT (SEE STEP 2)  
CONNECT DISCONNECTED CONNECTOR FROM NEW LIGHT TO OEM BLIS SENSOR.



**STEP 9**

**ASSEMBLE BLIS SENSOR**

ASSEMBLE BLIS SENSOR TO BLIS HEAT SINK USING SCREWS FROM STEP 2

REPEAT STEP 8 & 9 ON OPPOSITE SIDE



**STEP 10**

**CONTINUE TO BLIS MODULE INSTALLATION**

FEED WIRE HARNESS TO INSIDE OF LIGHT

REPEAT ON OPPOSITE SIDE



**STEP 11**

**COMPLETE BLIS MODULE INSTALLATION**

SET BLIS MODULE INTO NEW TAIL LIGHT. LEAVE NO GAPS BETWEEN HOUSING AND MODULE.

ASSEMBLE BLIS MODULE TO NEW TAIL LIGHT USING 4 SCREWS FROM STEP 1



**STEP 12**

**INSTALLATION COMPLETE**

TEST ALL FUNCTIONS BEFORE DRIVING ON THE ROAD

TITLE: **2019-2024 DODGE RAM 1500**

PART NUMBER: **311477 / 311478**