

# Instructions

## Rear Adjustable Swaybar

**N.B:** This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

**Note - this swaybar can be installed while vehicle is on its wheels at ride height - on flat level ground.**

**Application -** Dodge 1500  
- 2WD 2009-2018

*Always refer complete catalogue listing*

**Confirm vehicle brake is on or wheel is chocked.**

- Start by loosening the swaybar links. But don't remove nuts yet.

**Lubricant may be required to prevent thread damage**

- Loosen and remove D mount saddles. Then completely remove swaybar from vehicle.
- Grease new supplied D mount bushings with supplied grease. Bolt up swaybar with new supplied saddles and bolts.
- Start by bolting adjustable swaybar up to swaybar link - the medium setting is initially preferred.
- Road test - re-check all bolts after 100 miles travelled.

**Contents -** 1x 22mm rear swaybar  
- 2x D mount bushings  
- 2x D mount saddles  
- 4x M10 bolts  
- 4x washers  
- Grease



**Disconnect original swaybar link from swaybar**



**Mount new swaybar with supplied saddles and bolts/washers**



Drive carefully until you accustom yourself to vehicles changed behaviour

**N.B:** It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.