



LED TAIL LIGHTS

(2002-2006 1500)

(2003-2006 2500 / 3500)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Tail Light
- (1) RH Tail Light
- (2) Resistor Brackets
- (4) Vampire Clips
- (4) Phillips Bolts
- (4) Lock Nuts

TOOLS REQUIRED

- Phillips Screwdriver
- Pliers
- T-25 Screwdriver

1. Lower the vehicle tailgate. Locate and remove (2) T-25 screws from the tail light assembly. Firmly pull the tail light away from the vehicle to dislodge the (2) mounts from the vehicle bed.
Note: Verify the rubber mounts remained in the bed. If the rubber mounts are stuck to the tail light posts, remove the rubber and re-install into the bed mounting holes.
2. Unplug the electrical connector from the tail light by sliding the red lock outwards, and then pressing the tab to release the connectors.
3. Secure the tail light resistor to the included mounting bracket using the included (2) Phillips bolts and (2) lock nuts. The vampire clips will be used to secure the resistor to the inside of the vehicle bed.
4. Plug the tail light harness into the vehicle harness connector until the connectors audibly click into place and re-engage the lock. Then, mount the resistor to the inside of the bed away from the tail light using the (2) vampire clips.
5. Press the tail light to the vehicle bed, ensuring the tail light seats into the rubber mounts. Secure into place using the original (2) T-25 screws.
6. Repeat Steps 1-5 for the remaining tail light assembly.

Installation is now complete.