



# Silver Bullet

Throttle Body Spacer

PN 46-34003

## Important!

Please verify the parts list and read all instruction steps before you begin installation.

**Make:** General Motors Trucks and SUV

Model	Year	Engine	Model	Year	Engine
Escalade/ESV/EXT	07-12	6.0/6.2L	Denali	07-12	6.0/6.2L
Avalanche	07-12	5.3/6.0L	Sierra	07-12	4.8/5.3/6.0
Silverado	07-12	4.8/5.3/6.0	Yukon	07-12	4.8/5.3/6.0
Suburban	07-12	5.3/6.0L	Yukon Denali	07-12	6.0/6.2L
Tahoe	07-12	4.8/5.3L	Yukon XL	07-12	5.3/6.0L

1. Remove engine sight cover. Disconnect PCV hose from air inlet tube. Loosen and remove air inlet tube from Mass Air-Flow sensor (MAF) and throttle body.
2. Remove the Throttle Air Control (TAC) harness from throttle body. Loosen and remove the retaining bolts and nuts from throttle body. Remove the studs from the intake manifold using a 6-point 4mm socket.
3. Install the aFe Silver Bullet throttle body spacer (AIR IN engraving side faces the throttle body), a gasket and throttle body onto intake manifold. Using the washers and longer bolts secure the throttle body to intake manifold. Tighten the bolts to 10 Nm (89 lb/in).
4. Remove air inlet anchor from top of manifold, install one-inch extension with countersunk screw and reinstall air inlet anchor into the extension (Not necessary if you have an aftermarket intake installed). Reconnect TAC wire harness.
5. Reinstall air inlet tube and PCV vent hose. Reinstall engine sight cover.



### Parts List

- 1 aFe Silver Bullet Spacer
- 1 Gasket
- 4 6mm x 70mm bolts
- 1 6mm countersunk screw
- 4 6mm lock washers
- 4 6mm flat washers
- 1 6mm one-inch extension

**advanced FLOW engineering**

252 Granite Street, Corona, CA 92879

Support: 951-493-7100

[www.aFePower.com](http://www.aFePower.com)