

Design Engineering Inc.

604 Moore Road
Avon Lake, OH 44012



THERMAL TUNING PRODUCTS

Installation Instructions

DEI Cell Saver™

PART NO. 010480

KIT CHECKLIST	
1	Cell Saver Material
1	Cool Tape

NOTE
Measure twice, cut once!

DIRECTIONS

- 1 - Properly remove your vehicles battery and place on a secure surface or workbench.
For best results, remove any dirt, debris, and battery acid prior to installation. Old corrosive battery acid can be removed by using baking soda and water (use safety precautions such as protective eye wear)
- 2 - Wrap the Cell Saver material around the battery. Measure and mark where the piece overlaps.
- 3 - Use a razor or scissors to cut the excess material.
- 4 - Use the Cool Tape which is provided, to secure each end to it self.
- 5 - Place treated battery in vehicle and reconnect the battery.