



LED LICENSE PLATE LIGHTS

(01-13 SILVERADO)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) LED Lights

TOOLS REQUIRED

Soft Pry Tool

SKU# S113890



STEP 1

Using a soft pry tool depress the clip towards the front of the light, pull the light away from the bumper.



STEP 2

Twist the light socket and remove the factory light.



STEP 3

Remove the factory light bulb and install the LED light plug into the socket. Test the lights for functionality prior to re-installing. If the light doesn't illuminate, rotate the LED plug 180* and try again.



STEP 4

Twist the light bulb socket into the LED light housing. Hook the back edge of the light onto the bumper and then press the light into the bumper. Installation is now complete.