

Wire Mesh Grille Instruction

The below install is for reference. The install is similar for all wire mess grille installations whether is Ford, Chevy or Dodge.

Tools Required: Socket Set / Adjustable Wrench/ cut tooling

NOTE: Be Careful not to scratch the grills Surface.

(1) Before installation, please check new mesh grille fitment for your vehicle model.

Open the box, take out new mesh grille, and put it into opening grille shell to test, to be sure it is match with your vehicle.



- (2) Remove grille shell from vehicle, then remove honeycomb stock from grille shell as above picture show
- (3) Place new mesh grille over the rear of grille shell, our mesh grille has holes around frame, each hole will fit the original grille shell clip, insert each clip into each hole of grille, then insert and push hardware tab on the clip, it will hold the clip and mesh grille firmly, mesh grille installation complete.



- (4) Reinstall grille shell is complete for installation.

These instructions are for reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend a professional installation for best results. We are not responsible for any damage caused by the installation. Thank you for choosing our product!