



20" SINGLE ROW LED LIGHT BAR BUMPER MOUNT

(2007-2013 CHEVROLET SILVERADO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Light Bar Mount
- (2) M8 Bolts

TOOLS REQUIRED

- 10mm Socket
- 13mm Socket
- Ratchet

SKU #S123319



STEP 1

Remove (3) 10mm bolts from the middle of the bumper.



STEP 2

Align the light bar mount into the bumper. Secure the light bar mount re-using the (3) 10mm bolts. Tighten until secure. Install the light bar into the light bar mount using the (2) M8 bolts (Light bar not included).

Installation is now complete.