



BED TIE-DOWN ANCHORS

(2007-2020 CHEVROLET SILVERADO)

INSTALLATION INSTRUCTIONS

CONTENTS

(4) Tie-Down Anchors
(4) Foam Pads
(1) Wrench

TOOLS REQUIRED

Plastic Pry Tool
Isopropyl Alcohol
Microfiber Cloth

SKU # S123325



STEP 1

Using a plastic pry tool, remove the plastic plug from the bed side.



STEP 2

With the plug removed, clean the surrounding area with isopropyl alcohol and a microfiber cloth. Once dry, apply the foam pad around the perimeter of the hole.

STEP 3



Align the tie-down anchor into the hole in the bed. Using the provided wrench, tighten the anchor to the bed until secure.

Note: Reaching under the bed rail to get behind the anchor may be necessary to get the anchor to grab the inside of the bed.

STEP 4



Repeat steps 1-3 to the remaining anchors.

Installation is now complete.