



REAR FRAME HOLE PLUG SET

(1999-2018 SILVERADO/SIERRA)

INSTALLATION INSTRUCTIONS

CONTENTS

(4) Frame Hole Plugs

TOOLS REQUIRED

Mallet



STEP 1

Locate the (2) circular holes in the rear circular frame.



STEP 2

Press (1) frame plug into each circular holes in the vehicle frame. Ensure the plug is fully inserted, lightly tapping with a mallet may be necessary.

Repeat steps 1-2 to the opposite side of the vehicle. Installation is now complete.