



---

# CENTER CONSOLE LID LATCH

(2007-2013 CHEVROLET SILVERADO)

---

## INSTALLATION INSTRUCTIONS

## CONTENTS

---

(1) Center Console Lid Latch

## TOOLS REQUIRED

---

T-20 Torx Screwdriver  
Phillips Screwdriver

**STEP 1**

Open the center console lid. Remove (4) T-20 Torx screws. Starting from the bottom, remove the plastic panel from the center console lid.

**STEP 2**

Remove (2) Phillips head screws from the center console lid latch. Remove the latch from the center console lid.

---

**STEP 3**

Install the new center console lid latch to the center console lid reusing original hardware. Re-install the plastic panel onto the center console lid reusing original hardware.

Installation is now complete.