



CUSTOM FIT ALL WEATHER FLOOR LINERS

(2019-2023 SILVERADO - CREW CAB)

(2019-2023 SIERRA - CREW CAB)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Floor Liner
- (1) RH Front Floor Liner
- (1) Rear Seat Floor Liner

TOOLS REQUIRED

Vacuum Cleaner

STEP 1
[FRONT]

Clean the vehicle floor using a vacuum cleaner.

Locate the vehicle floor anchors. Firmly lift the original floor mats from the anchors, if applicable.

STEP 2
[FRONT]

Fit the new floor liner into the vehicle and onto the mounting anchors. Firmly press the floor liner into the floor anchors when properly aligned.

Repeat steps 1-2 for the remaining front floor liner.

STEP 3
[REAR]

Clean the vehicle floor using a vacuum cleaner.

STEP 4
[REAR]

Lift the front of the under-seat storage area divider, and fit the rear of the rear seat liner under the divider. Then, place the divider down onto the floor liner and evenly fit the remaining front section of the floor liner onto the vehicle floor.

Installation is now complete.