

# LED THIRD BRAKE LIGHT

(2007-2013 SILVERADO/SIERRA 1500)

(2007-2014 SILVERADO/SIERRA 2500/3500)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) LED Third Brake Light

### TOOLS REQUIRED

---

T-20 Torx Screwdriver



---

**STEP 1**

Remove (2) T-20 Torx screws from the third brake light housing.



---

**STEP 2**

Unplug the electrical connector from the original third brake light.

### STEP 3



Plug in the third brake light assembly. Test the light for functionality.

**Note:** If the new brake light connector does not easily plug into the vehicle connector, gently bend the pins of the brake light connector upwards towards the connector wedge lock with a small pry tool. Slightly bend and test the connection. Repeat until the connector easily fits, seats, and latches properly.

### STEP 4



Install the new third brake light into the vehicle reusing original hardware.

Installation is now complete.