

LED THIRD BRAKE LIGHT

(1999-2006 SILVERADO)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LED Third Brake Light

TOOLS REQUIRED

Phillips Screwdriver
Plastic Pry Tool

STEP 1



Remove (2) Phillips head screws from the vehicle third brake light. If necessary, work the brake light away from the vehicle cab using a plastic pry tool.

STEP 2



Unplug the vehicle third brake light from the connector inside the cab. Remove the third brake light from the vehicle.



STEP 3

Plug the new third brake light into the vehicle wiring harness. Then, fit and secure the new third brake light into place using the original (2) Phillips head screws. Tighten the hardware evenly until fully secure.



STEP 4

Installation is now complete.