Sway Bar End Link Kit

GM 1500 | 2014-2018

Part #: 121634

Rev. 03162021

491 W. Garfield Ave., Coldwater, MI 49036 • Phone: 517-279-2135

Web: www.bds-suspension.com • E-mail: tech-bds@ridefox.com

SAFETY WARNING

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Remove old sway bar link components. Start by loosen the 3/8" nut, then remove the stem bushings, stem washers, sleeve and bolt.
2. The new components will be assembled in the same manner as those being replaced.
3. Place1 stem washer followed by a stem bushing on the 3/8"x 9" bolt. Place the components through the sway bar.
4. Place another stem bushing and washer on the bolt, followed by the 5" sleeve.
5. Place stem washers and bsuhings in the same configuration on the lower control arm.
6. With the assembly completed on both sides of the vehicle, tighten the 3/8" nut until the bushing begins to form to the control arm. Reference Figure 1 below if necessary.

Box Kit

Part #	*Qty*	*Description*
21	2	.625" x .083" x 5.00" Sleeve
37024	2	3/8"-16 Nylock Nut
4805G	8	Small Stem Bushing
B389G5	2	3/8"-16 x 9" Bolt
S10024	8	Stem Washer

FIGURE 1

