



---

# MOLDED FLOOR LINERS

(1999-2006 SILVERADO)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Front Floor Liner
- (1) RH Front Floor Liner
- (1) Rear Floor Liner

### TOOLS REQUIRED

---

Vacuum Cleaner

SKU # S217242



1. Remove any current floor liner/mat from the vehicle.
2. Clean the vehicle floor using a vacuum cleaner.
3. Place the appropriate floor liner to the vehicle floor. Ensure the contours of the liner meet the vehicle floor.  
-**Driver Side Front:** Ensure proper clearance between the liner and the throttle pedal.
4. Repeat Steps 1-3 for all remaining floor liners. The liners will lay flat over time after experiencing heat and use.

Installation is now complete.