



RUST BUSTER

RB7396L & RB7396R
2014-2018 Chevy/GMC
Silverado/Sierra 1500
Silverado LD/Sierra Limited (2019 Only)
Front Cab Mount



REQUIRED TOOLS

Jack Stands or Lift
Mig Welder
Paint/Primer
Hand Grinder
Cutting Wheel or Torch
Welding Gloves
Welding Hood/Shield
Ear & Eye Protection
Sockets & Ratchet
Fire Extinguisher
Paint Marker

KIT CONTAINS

Front Cab Mount



**RUST
BUSTER**

RB7396L & RB7396R

2014-2018 Chevy/GMC

Silverado/Sierra 1500

Silverado LD/Sierra Limited (2019 Only)

Front Cab Mount

QTY

1



RUST BUSTER

RB7396L & RB7396R 2014-2018 Chevy/GMC Silverado/Sierra 1500 Silverado LD/Sierra Limited (2019 Only) Front Cab Mount

1) PREPARING YOUR VEHICLE

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

Keep all flammable materials away from the vehicle work area.

2) PREPARING YOUR WORKSTATION

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



RUST BUSTER

RB7396L & RB7396R

2014-2018 Chevy/GMC

Silverado/Sierra 1500

Silverado LD/Sierra Limited (2019 Only)

Front Cab Mount

3) PREPARING FOR YOUR INSTALL

Remove the factory cab mount bolt and bushing, and lift the cab.

4) CUT

Remove the factory front cab mount.



Grind the frame rail free of rust and debris, revealing bare metal.



Coat the work area with a weld through primer to help prevent against further rust development.



5) WELD

Remove any potential fire hazards from the work area. Following proper welding procedures, tack weld the part on before welding it on. 100% weld around all edges.



6) PAINT AND PROTECT

Coat the part and work area with a primer or other rust inhibitor to help prevent or reduce the risk of rust formation.



We recommend our Rust Buster Rust Converter and Primer Spray Paint.

7) REINSTALL

Reinstall the cab mount bolt and bushing.