



MAXTRAC SUSPENSION
4522 E EISENHOWER CIR
ANAHEIM, CA 92807
714-630-0363
WWW.MAXTRACSUSPENSION.COM
SALES@MAXTRACSUSPENSION.COM

**PRODUCT: 401500 REAR LOWERING SHOCK EXTENDERS
2014 GM 1500 PICKUP 2WD & 4WD**

PARTS LIST

QTY

| | |
|-----------------------------|---|
| SHOCK EXTENDER | 2 |
| GUIDE PLATE | 2 |
| 1/2-13X1 HEX CAP SCREW | 4 |
| 1/2-13 JAM NUT | 4 |
| 1/2" FLAT WASHER | 4 |
| 1/2" SPLIT LOCK WASHER | 4 |
| 7/16-14X1 1/4 HEX CAP SCREW | 2 |
| 7/16-14 NYLOCK NUT | 2 |
| 7/16" FLAT WASHER | 4 |

PLEASE DOUBLE CHECK THE PARTS LIST BEFORE BEGINNING INSTALLATION, TO ENSURE ALL PARTS ARE PRESENT, IF THERE IS SOMETHING MISSING, PLEASE CONTACT MAXTRAC IMMEDIATELY 714-630-0363

READ THE INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE BEGINNING THE INSTALLATION.

PRIOR TO INSTALLATION:

1. Factory service manual is recommended to have on hand.
2. Secure and properly block vehicle prior to beginning installation
3. Always wear safety glasses when using power tools or working under the vehicle
4. Modifications to any part will void the warranty associated with that product.

After removing parts from vehicle, save hardware for reinstallation

IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHENEVER INSTALLING NEW SUSPENSION. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER YOUR VEHICLE'S RIDE HEIGHT IS ALTERED.

INSTALLATION INSTRUCTIONS - 401500

1. SUPPORT AXLE WITH AN ADJUSTABLE JACK & UNBOLT BOTH SHOCKS AT THE AXLE.



2. SLIDE MAXTRAC EXTENDER OVER ORIGINAL MOUNT ON THE AXLE & INSTALL USING PROVIDED BOLTS



3. INSTALL SQUARE PLATE INSIDE THE ORIGINAL EXTENDER & RUN THE 7/16" BOLT THROUGH & TIGHTEN ALL THE BOLTS.



4. RE-INSTALL THE SHOCK INTO THE MAXTRAC EXTENDER USING THE ORIGINAL HARDWARE & TIGHTEN.

