Instructions Body Mount Bushings

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 1 of 2

Application - Ford F250 - Super Duty 1999-2016

(Refer current catalogue for complete listing)

Note: Any rusted nuts or bolts will require lubricant prior to disassemble.

Contents - Bushing 91544 x8

- Bushing 91937 x8
- Bushing 91938 x2
- Washer 63x13x3 x2
- The carpet will have to be lifted first plastic lift the trim up near the doors to do so.
- On some models, you may have to remove rear seat.

Note - remove and replace mounts from one side of vehicle at a time.

- Start by un loosening the upper nuts near the radiator, then un-bolt the lower bolts
- Loosen and remove all mounts from LH side and loosen only mounts from RH side.
- Proceed to lift body use a jack and timber. The timber will prevent any damage to the floor.
- Start to remove each mount. Note the original mounts will need to be un-clipped from the frame with a screw driver.
- For position #1 near radiator, use supplied flat washer with OE nuts and bolts. Refer page 2.
- For positions #2 and #4, you may require heat to burn out old rubber from steel.
- For position #3, re-use the lower rectangular OE mount.

Note - do not tighten any bolts until all mounts are replaced.


Re-check all bolts after 500kms travelled.

Refer Page 2 Diagram

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Page 2 of 2

Instructions Body Mount Bushings



Position #1

Position #2



Upper 91937

Lower 91544

Upper 91937



Washer 63x13x3



Position #3

Upper 91938



Position #4



Upper 91937

Lower 91544

Position #5



RE-USE ORIGINAL LOWER MOUNT HERE

Upper 91937

Lower 91544

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.