

Ford

KIT104 – KIT204

At Apex, customer safety is our top priority, and steering is a CRITICAL safety component.

****Be sure the installer has read and follows these instructions.****

Failure to follow these instructions may result in loss of control of the vehicle, accident, and injury.

Failure to follow install instructions and use correct install tools may also void the warranty.

Install instructions should follow vehicle through entire install process, including alignment, which requires safety-critical torque and process to complete.

Installation

1. Press lower ball joint, install nut and torque to 35 ft. lbs.
2. Press in the upper ball joint, install castle nut and torque to 70 ft. lbs. Advance castle nut to next slot and install cotter key.
3. Retorque the lower ball joint nut to 150-160 ft. lbs.

PLEASE NOTE:

Apex ball joints are designed and manufactured with very close tolerances and precise factory preloads.

This may cause an initial period of tight steering and /or memory steer after install. As with many performance upgrade parts, these may require a performance break in period of 200-500 miles before they settle into your vehicle.

Thanks for choosing Apex Performance upgrade!