

ARMOR GRILLE

SKU # AMFMFA00118

Product Installation Instructions

Fitment : 2011-2016 Ford F250

STEP 1



Open the hood,remove four 10 millimeter bolts. Carefully lean the grille forward and located the metal clips at the bottom and use the long flat blade screwdriver to push down and release these five clips.

STEP 2



Then pull the grille off the truck.

STEP 3



Put the new grille to the vehicle,line up the mounting taps on the bottom of the grille and push them all into place.

STEP 4



The red wire connects to headlights,the black wire connectsnegative of the battery.

STEP 5



Reinstall the four 10 millimeter bolts to finish the installation of the new grille.