



INSTALLATION INSTRUCTIONS

2007-2018 Chevy Silverado 1500/2500/3500 Part Number- GM-4500

Note- Installation time 3-5 hours

PARTS LIST:

2	Step Board	25	Wire ties
1	Controller assembly w/ harness	1	Rivet install tool
1	Front driver side linkage	2	Fuses
1	Rear driver side linkage	2	Hex flange bolts M8x25mm
1	Front passenger linkage	2	Wired magnetic induction module
1	Rear passenger linkage	4	Magnets
8	Hex flange bolts M8x30mm	4	LED Lamp
8	Socket cap screw M6x25mm	1	Power board switch
4	Flush head rivet M8x18mm	1	Hex flange nut M8

