


**STEP 1**  
**[FRONT]**

Remove any existing floor mat/liner from the vehicle. If the floor mat/liner is anchored into the floor, firmly pull upwards to release the mat/liner from the anchor.


Clean the vehicle floor using a vacuum cleaner.



**STEP 2**  
**[FRONT]**

**Floor Anchor for Driver Side:** Fit the bottom of the included anchor to the bottom-side of the floor liner. Then, fit the top portion to the top of the anchor, and press together until the anchors snap together. Repeat for the remaining anchor.

If the vehicle does not have OEM anchor points, the included anchor mounts will mount into the floor using a self tapping screw into the vehicle carpet & padding using a flathead screwdriver.



**STEP 3**  
**[FRONT]**

Fit the floor liner to the vehicle. Ensure to route under the vehicle throttle pedal. Press the anchor points firmly downwards into the vehicle anchor.

Repeat this step for the remaining front floor liner.



**STEP 4**  
**[REAR]**

Remove any existing floor mat/liner from the vehicle. Clean the vehicle floor using a vacuum cleaner.



**STEP 5**  
**[REAR]**

Evenly fit the new floor liner onto the vehicle floor. Adjust to best fit the vehicle.

All floor liners will begin to lay flat over time in the vehicle when exposed to heat and use.

Installation is now complete.



---

# FLOOR LINERS

(2017-2026 F-250 / F-350 - SUPER CREW CAB)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Front Floor Liner
- (1) RH Front Floor Liner
- (1) Rear Floor Liner
- (2) Floor Anchors

### TOOLS REQUIRED

---

- Vacuum Cleaner
- Flathead Screwdriver (Optional)

SKU # SD77680