



2011-15 Mustang 3.7L V6
 2011-15 Ford F-Series Truck 3.7L/3.5L V6
73mm Throttle Body
Part # 1822



**Special Tools
 Required:**

- No special tools required

Install Time:

Approximately
 30 Mins

Difficulty:


1 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

- Disconnect the negative battery terminal.

STEP 2



- Disconnect the (2) breather hoses attached to the inlet tube.

STEP 3 STEP 4

- Loosen the clamps at each end of the inlet tube, at the throttle body and at the air filter box. Remove the inlet tube and set it aside.



- Unplug the electrical connector from the side cover of the throttle body. Pull the black wire harness mount out of the hole in the throttle body.

STEP 5

- Unbolt the throttle body from the intake manifold and remove.

STEP 6

- Wipe off the rubber o-ring gasket as it will be reused with the BBK throttle body.

Revised 2/25/2013



GO TO NEXT PAGE

WWW.BBKPERFORMANCE.COM

For any questions, email us:
tech@bbkperformance.com

installation instructions

1

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.



2011-15 Mustang 3.7L V6
 2011-15 Ford F-Series Truck 3.7L/3.5L V6
73mm Throttle Body
Part # 1822

STEP 7



- Using the supplied bolts, install the BBK throttle body onto the intake manifold and tighten the bolts. Reconnect the electrical connection.

STEP 8



- The stock air inlet tube will work with the BBK throttle body. Just open the clamp all the way up before installing. Trim off the 2 small tabs on the top of the stock rubber inlet tube so it will fit all the way onto the BBK throttle body. A little WD-40 or light grease may help this process.

STEP 9

- With the inlet tube installed and the clamps tight, reconnect the breather hoses. Reconnect the negative battery terminal.

Hardware Included

- KIT1821/22
 - HDW183 Bolts, SHCS M6-1.0X60 (4pcs)



Join our Facebook page
www.facebook.com/bbkperformance



Follow us on Twitter
 @bbkperformance



Check us out on Youtube
www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

For any questions, email us:
tech@bbkperformance.com

installation instructions

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

Revised 2/25/2013