

**Design Engineering, Inc.**

604 Moore Road  
Avon Lake, OH 44012



*THERMAL TUNING PRODUCTS*

**Installation Instructions**

**DEI Boom Mat™**

PART NO. 050200 through 050212

KIT CHECKLIST	
PN #	Boom Mat Material

NOTE
It is not required to clean the surface of the area that the Boom Mat is being applied to but it does increase its bond strength.

**DIRECTIONS**

- 1 - Although Boom Mat will stick to anything, it is a good idea to make sure the installation area is clean and free of dirt, grease, oil, wax, moisture, and rust will improve the bond between Boom Mat and installation area.
- 2 - Trim Boom Mat to desired size by using a shape razorblade or scissors. Making a template will aid proper and professional installations. Remove the backing to expose the adhesive and carefully apply to clean and dry desired area.
- 3 - After Boom Mat is set in proper location, use a flat rolling pin and apply pressure to ensure a strong bond between the Boom Mat and installation surface.

