

SKU:T543346

Cube Light Mounting Brackets (15-18 F150)

Contents:

- (1) Left Bracket
- (1) Right Bracket

Tools Required:

13mm Socket and Ratchet



Step 2\\

Carefully remove the hood hinge bolts and install the Cube Light Brackets. Align the hood hinge to the chassis using the mark made in Step1. **Note: It may be helpful to have an assistant hold the hood. Repeat the process on the other side.



Step 1\\

Locate the (2) 13mm hood hinge bolts. Using a marker, mark when the hinge in relation to the chassis for ease of future re-alignment.



Install is now complete.