



CHROME MIRROR COVERS SKULL CAP REPLACEMENT

(2015-2019 F150 W/ STANDARD MIRRORS)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Mirror
(1) RH Mirror

TOOLS REQUIRED

Soft Pry Tool

SKU # T543604

STEP 1

Begin by carefully prying off the factory mirror covers. They are clipped onto the mirror in (4) locations. Using a soft prying tool, pry the mirror cover way from the mirror. Start on the outer edge and work your way up the mirror.

STEP 2

Align the (4) mirror cover clips with the factory mirror. Then, firmly press the mirror cover onto to the mirror.

Maintenance and Care:

Hand wash with automotive grade soap and water. Dry using a microfiber towel. Avoid automatic car washes as they can scratch the finish.