



REAR WHEEL WELL LINERS

(2015-2020 F-150)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Driver's Side Liner
- (1) Passenger's Side Liner
- (8) U-Clips
- (8) Phillips Screws

TOOLS REQUIRED

- Phillips Screwdriver
- Pliers

SKU # T546993



STEP 1

Install (2) U-Clips into the pre-drilled locations inside the wheel well.



STEP 2

Place the wheel well liner into the vehicle. Install (2) Phillips screws into the fender liner, but do not tighten.

STEP 3

Using (2) U-Clips as nuts, install (2) Phillips screw into the fender liner. The U-Clip goes behind the sheet metal of the wheel well. Hold the U-Clips in place with pliers while tightening.

Note: Spread the wings on the U-Clip before inserting the screw for ease of installation.

STEP 4

Tighten all the Phillips screws, repeat procedure for other side.

Installation is now complete.