



HOOD SCOOP

(2015-2021 F-150)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Hood Scoop
(1) Roll of 3M Tape

TOOLS REQUIRED

Scissors

SKU # T550056



STEP 1

Thoroughly clean the entire hood.



STEP 2

Apply the supplied 3M tape to the edge of the side skirt.



STEP 3

Ensure the hood is completely dry prior to installing the hood scoop. Test fit the scoop for best fit prior to removing the tape backing. Once comfortable with the positioning of the hood scoop, remove the tape backing. Apply firm even pressure to the taped areas to ensure proper adhesion.