



LED 3rd Brake Light - Smoked (09-14 F150)



Step 1 Locate, and remove the (2) Phillips head screws.



Step 3Take the new Axial light, and install the two light harnesses into the factory light bulb sockets. Install the brake light wire into the middle socket. The cab light can be installed into either end socket. Test for proper function.



Step 2\\
Remove the (3) light bulb sockets by twisting them counter clockwise. Then remove the (3) bulbs by gently pulling away from the socket.



Step 4 Install the (2) factory screws and tighten fully.