



UNDER SEAT STORAGE

(2015-2025 F-150 SUPERCAB / SUPERCREW)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Large Storage Bin
- (1) Small Storage Bin
- (2) 'L' Brackets
- (4) M6x1.00x50mm Bolts
- (8) M6x1.00x20mm Bolts
- (8) Flat Washers
- (8) M6 Nuts

TOOLS REQUIRED

Socket Wrench 10mm Socket 10mm Wrench



STEP 1



Install the (2) 'L' Brackets under the smaller section of the bench seat using (2) M6x1.00x20mm bolts, (2) flat washers, and (2) M6 nuts on each bracket.



STEP 2

Install the larger bin into the vehicle, align the holes along the back of the bin with the preexisting holes in the rear seat bracket. Using (4) M6x1.00x50mm bolts, (4) flat washers, and (4) M6 nuts, secure the large bin into place.





STEP 3

Slide the smaller bin into the 'L' Brackets, and installation is complete.